
# AssetProfile

Adds a new asset profile to the solution. The system references this profile during asset generation and uses it in combination with the asset file path and the asset ID.




| Item | Description |
| --- | --- |
| Destination path | Specifies the folder in the solution where the system places the new item. Click **Browse...** to select an existing folder. |

| Item | Description |
| --- | --- |
| Name | Sets the name of the new item. The system references this name through the `$AssetProfileName` macro variable during asset generation. |
| Description | Describes the new item in detail. |
| Annotations | Serves as storage for notes and other project-related information. The system exports the entered text to the HMI report. |
| URI | You can set any URI. If you enter a valid URI, clicking it launches the browser and displays the contents of the link. |

Revision #2
Created 2026-06-22 05:38:18 UTC by Tsuyoshi.Kato
Updated 2026-09-14 04:12:19 UTC by Tsuyoshi.Kato